



SANITIZED® GLUE GROUT

DESCRIPTION

Davco *Sanitized*® Glue Grout, is a white premixed, acrylic based, flexible, thin bed, internal wall tile adhesive. It is ready to use directly out of the container. Davco *Sanitized*® Glue Grout can also be used as a flexible premixed grout.

USES

As an Adhesive:

- *Sanitized*® Glue Grout can be used for thin bed fixing of most types of porous ceramic & marble wall tiles.
- *Sanitized*® Glue Grout can be used to lay tiles onto concrete, cement render, plasterboard and fibre cement walls.

As a Grout:

- *Sanitized*® Glue Grout can be used for grouting small areas of internal wall applications, but only for application's involving less than 0.5m².
- *Sanitized*® Glue Grout can be used in grout joints between 1mm and 3mm wide.
- When grouting larger areas, it is recommended that Davco *Sanitized*® Colorgrout or Liquid grout be used.

FEATURES AND BENEFITS

- *Sanitized*® Glue Grout is a flexible adhesive, which can accommodate movement in the building boards.
- Being white in colour it can be used to lay marble and translucent ceramic tiles without the risk of the adhesive colour showing through.
- *Sanitized*® Glue Grout surpasses the Australian Standard AS2358-1990.

SURFACE PREPARATION

As an Adhesive:

- The substrate must be sound and firmly fixed, free from dust, grease, oil, wax, curing compounds and other loose contaminating materials.
- Ensure all surfaces are thoroughly dry prior to tiling.

- Cement rendered walls should have a woodfloat finish. Newly rendered surfaces must be allowed to cure for at least 7 days prior to tiling.
- Fibre cement and plasterboard surfaces must be primed with Davco 4 in 1 Primerflex/Additive prior to commencing tiling.
- Previously painted surfaces must be sanded back to expose at least 80% of the original substrate to provide a key for the adhesive.
- Ensure all cement surfaces are free from release agents, especially tilt up slabs.

Movement joints should be provided as follows:

1. Over movement joints in the background.
2. At a junction between different background materials.
3. At fixtures interrupting the tile surface.
4. At internal vertical corners.
5. At a maximum of 5 metre intervals in a grid pattern.

Note: Movement joints should go right through the tile and adhesive bed to the background and be kept free from dirt and adhesive droppings. Movement joints should not be less than 6mm nor greater than 10mm wide.

All movement joints that are 6mm wide should be filled with Davco *Sanitized*® Colorcaulk. Joints 6mm - 10mm wide should be filled with a polysulphide filler

As a Grout:

- Ensure all joints are free from dust, dirt, loose contaminating particles and excess water.
- Excess adhesive must be raked out of the joints prior to the application of *Sanitized*® Glue Grout.

APPLICATION

As an Adhesive:

- Use a 6mm x 6mm notched trowel for the installation of flat back tiles up to 150mm x 150mm.
- For the installation of wall tiles larger than 150mm x 150mm, or tiles with ribs, use a 10mm x 10mm notched trowel.
- Using the appropriate notched trowel, spread approximately 0.5m² of *Sanitized*® Glue Grout at a time.



SANITIZED® GLUE GROUT

- Press tiles firmly into position before the adhesive skins. Ensure that the tiles are well bedded and that no voids occur under the tiles.
- Tiles with lugs or grooves must be butter coated before bedding in the adhesive.

As a Grout:

- Using a rubber float or squeegee, work the grout paste deep into the joints, making sure the grout is not just sitting on top.
- Remove excess grout from the surface of the tiles with the float or squeegee using a diagonal motion to avoid dislodging the embedded grout.
- A primary clean-up should be done next by wiping over with a damp cloth or sponge.

PRECAUTIONS

- Do not use in temperatures above 40°C and below 10°C.
- Do not use in grout joints wider than 3mm.
- Do not use to bond two impervious surfaces together.
- Do not use in areas of water immersion such as shower floors, swimming pools, spas etc.
- Do not use for grouting areas any larger than 0.5m² – for larger areas, use Sanitized Colorgrout or Liquid Grout.
- For a full MSDS on this product contact your Davco State office.

COVERAGE

Using a 6mm x 6mm notched trowel approximately 0.5m²/500ml.

CLEAN UP

Tools and other equipment can be cleaned with water while *Sanitized*® Glue Grout is still wet.

PACKAGING

Available in 500ml containers.

SHELF LIFE

Up to 12 months in unopened containers stored in a cool dry place.

TECHNICAL DATA

Properties:

Appearance:	Thick White Paste
Specific Gravity:	1.56 kg / L
Working Time at 20°C:	20-30 minutes
Curing Time at 20°C:	24 hours

DISCLAIMER

The use of this product is beyond the manufacturer's control, and liability is restricted to the replacement of material proven faulty. The manufacturer is not responsible for any loss or damage arising from incorrect usage. All workmanship must be carried out in accordance with AS 3958.1 - 1991.

The information contained herein is to the best of our knowledge true and accurate. No warranty is implied or given as to its completeness or accuracy in describing the performance or suitability of the product for a particular application. Users are asked to check that the literature in their possession is the latest issue.

PAREXDAVCO

ParexDavco (Australia) Pty Limited

ABN 28 093 876 558

67 Elizabeth Street Wetherill Park NSW 2164 Australia

Telephone: 61 2 9616 3000 Facsimile: 61 2 9725 5551

Toll Free Technical Advice Line: 1 800 653 347

Email: technical@parexdavco.com.au Website: www.parexdavco.com.au

